


BACKROADZ[®] SUV TENT MODEL 19100



INSTRUCTIONS

Napier tents have a one (1) year warranty period from the time of purchase against defects in improper

workmanship. Normal wear and tear, seam leakage through needle holes, and improper use, abuse, or

Replacement parts may be new or re-built at Napier's sole discretion. E-Warranty claim forms can be

alteration are not covered under the warranty policy. Napier Outdoors will replace or repair defective parts.

completed online at www.napieroutdoors.com/warranty. Proof of purchase (receipt) must be provided. If you

do not provide proof of purchase, or if your warranty period has ended, replacement parts can be purchased.

To order replacement parts, contact Napier Outdoors at 800-567-2434 (9:00 am - 5:00 pm EST),

visit www.napieroutdoors.com, or email customerservice@napieroutdoors.com

CAMPSITE SELECTION

- Select a smooth, level campsite clear of rocks, branches, and other hard or sharp objects
- Avoid areas with overhead power lines and tree limbs
- Park the vehicle in the chosen campsite

WARRANTY INFORMATION

• Turn the engine off and engage the parking brake

- 1. Clean and dry the tent
- 2. Fold all of the components into the tent
- 3. Roll the tent, using the pole bag as a guide
- 4. Secure with the tent tie straps and insert
- into the carrying bag
- 5. Store in a cool, dry place

CAUTION


- Do not use candles, matches, or open flames of any kind in or near the tent
- Do not cook inside the tent
- Build campfires downwind and several meters away from the tent. Be sure to fully extinguish fires before leaving a campsite or before retiring for the night
- Exercise extreme caution when using fuel-powered lanterns or heaters inside or around the tent. Use battery-operated lanterns whenever possible
- Do not refuel lamps, heaters, or stoves inside the tent
- Extinguish or turn off all lanterns before going to sleep
- Do not smoke inside the tent
- Do not store flammable liquids inside the tent
- NEVER run the vehicle engine when the tent is attached
- Do not install the tent when the temperature is below 0°C/32°F or when your vehicle is wet, it may cause damage
- Allow adequate ventilation inside the tent at all times
- Do not attempt to drive the vehicle with the tent attached
- Disconnect the battery or turn off the door lamps' so that they do not stay on when the hatch is open. This will reduce the risk of battery drainage.

WARNING

- Keep all flame and heat sources away from the tent fabric. The tent is made with flame-resistant fabric which meets CPAI-84 specifications. This does not make it fireproof. The fabric will burn if left in contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.
- To prevent carbon monoxide from entering the vehicle and tent area, do not run the engine, do not cook inside the tent, and do not use a gas heater in the tent. Carbon monoxide is dangerous to your health.
- Engine must be off and exhaust must be fully cooled before tent installation and use.

PACKAGE CONTENTS

Remove contents from the bag and ensure you have all components listed below.



If you are missing parts, please contact Napier O utdoors at 800-567-2434 | Monday - Friday or email customerservice@napieroutdoors.com

TENT SET UP

1 Lay out the tent with the vehicle sleeve facing the cargo area of your vehicle.

2 Assemble the tent poles by unfolding each section.

3 Locate the tent poles and insert diagonally into the

form an X.

pole sleeves. The center of the poles should cross and

NOTE: The poles may get stuck in the pole sleeve. Do not force the pole - gently lead it through the fabric sleeve.

